



COORDENADAS PUNTOS AUXILIARES		
Pto.	X	Y
P36	4618378.480	6372121.256
P37	4618289.777	6372136.911
P42	4617767.382	6372252.287
P43	4617770.811	6372248.239

COORDENADAS NARICES			
Pto.	X	Y	RADIO
N34	4617786.704	6372247.039	0.50
N35	4617364.846	6372338.748	1.00

COORDENADAS PUNTOS AUXILIARES		
Pto.	X	Y
P44	4617384.699	6372335.944
P45	4617373.556	6372333.614
P48	4617191.132	6372377.082
P49	4617103.988	6372399.868

COORDENADAS PUNTOS AUXILIARES		
Pto.	X	Y
P38	4618051.718	6372224.011
P39	4617964.574	6372246.797
P40	4617801.690	6372285.993
P41	4617790.546	6372283.664

COORDENADAS NARICES			
Pto.	X	Y	RADIO
N33	4617810.399	6372280.859	1.00
N36	4617335.999	6372383.542	0.50

COORDENADAS PUNTOS AUXILIARES		
Pto.	X	Y
P46	4617355.942	6372381.999
P47	4617355.431	6372378.783
P50	4616881.377	6372483.591
P51	4616792.674	6372499.246

